


### Gate Position Adjustment

- 1, Press "SET" (middle button) for 5 times continuously, the system will prompt "please adjust gate manually".
- 2, Push the gate to the target position and stop it for 3 seconds. The speaker prompt "beep" or the LED light flashes once, the system will take the current position as the target position.  
 \* The system will automatically determine whether the target position is left, right or middle target position.
- 3, Finally, push the gate to the middle target position and holding for about 10 seconds. The system will prompt "adjustment completed", then the whole program is finished.

\*In most cases, the system will automatically obtain the appropriate left position and right position, and the user only needs to adjust the middle position

## Parameter Setting

- 1 , Long press the "Set" button, till the nixie tube flashes.
- 2 , The "Menu" button for chosing the menu, the "Vaule" button for setting the parameter.
- 3, Long press the "Set" button again to exit and save the parameter..



| menu | function            | range | default | Parameter function description  |
|------|---------------------|-------|---------|---|
| 0    | machine number      | 1~99  | 1       | For 485 communication   |
| 1    | Unlock mode         | 1~6   | 1       | 1 : standard; 2 : IR1 respond to unlock<br>3 : IR4 respond to unlock. 4 : IR1 and IR4 respond to unlock.<br>5: Normal unlocking. 6: Normal locking.   |
| 2    | Keeping unlock time | 1~90  | 8       | Time unit: Second   |
| 3    | voice for open_L    | 0~9   | 0       | 0, thank you ; 1, come in ; 2, good bye ;<br>3,welcome ; 4,see you; 5,have a nice day ; 6, have nice trip ;<br>7, please put on your safety helmet ; 8, Verify success ; 9<br>null(mute);   |
| 4    | voice for open_R    | 0~9   | 3       |   |
| 5    | volume              | 1~9   | 5       | The higher the value, the higher the volume   |
| 6    | Main motor speed    | 1~25  | 15      | The higher the value, the higher the speed  |
| 7    | Slave motor speed   | 1~25  | 15      |   |
| 8    | Restore factory     | 0~2   | 0       | 1 : Automatic aging test<br>2 : Restore factory   |
| 9    | Show down range     | 1~30  | 10      | To control the effect of gate panel swing, the higher the value,<br>the earlier the braking   |
| 10   | Null                | 1~9   | 3       | Null  |
| 11   | n by n passing      | 0~1   | 0       | 0 : n by n passing function off<br>1 : n by n passing function on   |
| 12   | Locking control     | 0~9   | 2       | 0: When pedestrian pass through the middle sensor, the gate<br>will close.<br>1: When pedestrian reach the last sensor, the gate will close.<br>2: When pedestrian pass through the last sensor, the gate will<br>close.<br>3 ~ 9: After passing the last group of IR, the gate will close<br>with a delay (n-2 second) |
| 13   | Number of motors    | 0~1   | 0       | 0 : Dual motor<br>1 : Solo motor  |
| 14   | Language            | 0~1   | 0       | 0 : Chinese ; 1 : English   |
| 15   | Stacking control    | 0~1   | 1       | 0: No rebound in case of resistance   |

### Swing Barrier Series Quick Instructions V2

|    |  |     |   |  |
|----|--|-----|---|--|
|    |  |     |   | 1: Rebound in resistance   |
| 16 | Stacking sensitivity                   | 1~9 | 5 | The higher the value, the higher the sensitivity   |
| 17 | Retrograde control                     | 0~1 | 1 | 0: Retrograde trigger does not close the gate, only voice alarm<br>1: The gate will be closed by retrograde.   |
| 18 | Type of gate                           | 0~3 | 0 | 0: swing gate (quick pass gate)<br>1: Cylindrical swing gate (supermarket swing gate)<br>2: Wing gate.   |
| 19 | Gate open direction<br>When power off. | 0~2 | 2 | 0: Automatic. 1: Open to left. Open to right.  |
| 20 | Force of pushing the gate              | 1~9 | 5 | The greater the value, the greater the force. Excessive force may cause power restart. It is recommended to use the default value for 6.25A power supply   |
| 21 | Voice of beak in control               | 0~1 | 1 | 0: there is no voice prompt when the illegal intrusion event occurs.<br>1: There are relevant voice prompts when an illegal intrusion event occurs.  |
| 22 | IR Signal respond delay                | 1~9 | 3 | time=vaule*10ms  |
| 23 | Motors running direction               | 0~4 | 0 | 1: Forward rotation of main motor and reverse rotation of slave motor;<br>2: Reverse rotation of main motor and forward rotation of slave motor;<br>3: Forward rotation of main motor and forward rotation of slave motor;<br>4: Reverse rotation of main motor and reverse rotation of slave motor; |
| 24 | Clutch control                         | 0~1 | 0 | 0 : normal lock , 1 : normal unlock  |
| 25 | Hall mode of motor                     | 0~2 | 0 | 0 : auto , 1 : mode A , 2 : mode B   |
| 26 | Input filtering                        | 1~9 | 3 | Vaule*10ms   |
| 27 | IR anti pinch during unlocking stroke  | 0~1 | 0 | 0: Function off; 1: Function on;   |
| 28 | Anti tailing alarm                     | 0~1 | 0 | 0: Function off; 1: Function on;   |
| 29 | Sliding gate alarm threshold           | 0~9 | 2 | The larger the value, the greater the allowable offset position  |
| 30 | IR2 and IR3 respond to unlock          | 0~1 | 1 | 0: Function off; 1: Function on;   |

### Troubleshooting

| Fault code | Fault cause               | solution  |
|------------|---------------------------|---|
| E010       | No main motor is detected | Hall wire or motor wire is wrongly connected, and |

# Swing Barrier Series Quick Instructions V2

|      |                                       |  |
|------|---------------------------------------|--|
| E020 | No slave motor is detected            | motor Hall fault.  |
| E030 | Main and slave motor are not detected |  |
| E050 | Abnormal self-test                    | Wrong sequence of Hall phase or motor phase, motor fault, mechanical slipping or jamming |
| E090 | Voltage too low                       | Check the power supply.  |