


DC24V Heavy Duty Swing Gate Opener Manual



- ★ Thank you for purchasing this product
- ★ Please read and follow all warnings, precautions and instructions before installation and using
- ★ Periodic checks of the opener are required to ensure safe operation
- ★ Keep the manual for future reference

Table of Contents

Safety Installation Information	1-2
--	------------

Swing Gate Opener Part List	3
--	----------

Technical Specification	4
--------------------------------------	----------

Installation	5
• Installation Overview	5
• Dual Gate Overview	5
• Installation Step	6-13

How to adjust the limit switch for the swing gate opener ..	14
--	-----------


Control Board Instruction	16
• Remote Control	17
• Wire Diagram of the Control Board	17
• Function Description of the Control Board.....	20
• Control Board Parameters Setting	24

Smart Module Instruction	29
---------------------------------------	-----------


Safety Installation Information

1. READ and FOLLOW all instructions.
2. The gate opener is intended for use with class I vehicular swing gates.
Class I denotes vehicular gate opener (or system) dwellings, or a garage or parking area associated therewith.

Install the gate opener only when the opener is appropriate for the construction and the usage class of the gate.
3. Gate opening system designers, installers and users must take into account the possible hazards associated with each individual application. Improperly designed, installed or maintained systems can create risks for the user as well as the bystander. Gate system design and installation must reduce public exposure to potential hazards. All exposed pinch points must be eliminated or guarded.
4. A gate opener can create high levels of force during normal operation. Therefore, safety features must be incorporated into every installation. Specific safety features include safety sensors.
5. The gate must be properly installed and work freely in both directions prior to the installation of the gate opener.
6. The gate must be installed in a location so that enough clearance is provided between the gate and adjacent structure when opening and closing to reduce the risk of entrapment. Swinging gates shall not open into public access areas.
7. The opener is intended for use only on gates used for vehicles. Pedestrians must be supplied with a separate access opening. The pedestrian access opening shall be designed to promote pedestrian usage. The pedestrian access shall be located such that persons will not come in contact with the moving vehicular gate.




8. Pedestrians should never cross the pathway of a moving gate. The gate opener is not acceptable for use on any pedestrian gate. Pedestrians must be supplied with separate pedestrian access.
9. For an installation utilizing non-contact sensors, see the product manual on the placement of non-contact sensors (safety sensors) for each type of application.
 - a. Care shall be exercised to reduce the risk of nuisance tripping, such as when a vehicle trips the safety sensor while the gate is still moving.
 - b. One or more non-contact sensors (safety sensors) shall be located where the risk of entrapment of obstruction exists, such as the perimeter reachable by a moving gate or barrier.
10. Never mount any device that operates the gate opener where the user can reach over, under, around or through the gate to operate the controls. Controls are to be placed at least 6' (1.8m) from any part of the moving gate.




11. Controls intended to be used to reset an operator after 2 sequential activations of the entrapment protection device or devices must be located in the line of sight of the gate, or easily accessible controls shall have a security feature to prevent unauthorized use. Never allow anyone to hang upon or ride the gate during the entire travel of the gate.

Swing Gate Opener Part List




Gate Opener
2 pcs



Control box 1pc Control box Screws Pack

Control Box Kit



Remote Control
Optional


Remote Control x 2




Rubber Stopper
1 pcs



Rubber Stopper Screw
2 pcs




Manual Release Key
2 pcs




Post Bracket
6 pcs



Post Pivot Bracket
2 pcs



Bolt
12 pcs




Bolt
8 pcs




Clevis Pin
4 pcs



Hairpin Clip
4 pcs




Post Pivot Bracket
2 pcs



Spanner (Adjust
Limit Switch)

• Tools Required



Technical Specification

Specifications	
Input power	AC 110V/220V \pm 10%
Motor voltage	24V DC
Power	60W
Actuator speed	2.4 cm/s
Max. Actuator travel	440mm
Max single-leaf weight	350KGS
Max single-leaf length	3.8 meters
Ambient Temperature	-22°C ~ +55°C
Protection class	IP55
Max Gate Opening Angel	110°

Gate Weight (per leaf)	350KG(660lbs)	✓	NR	NR	NR	NR
	300KG(660lbs)	✓	✓	NR	NR	NR
	250KG(560lbs)	✓	✓	✓	NR	NR
	200KG(440lbs)	✓	✓	✓	✓	NR
	150KG(330lbs)	✓	✓	✓	✓	✓
	100KG(220lbs)	✓	✓	✓	✓	✓
		1.5M(5')	2M(6.5')	2.6M(8.5')	3.2M(10.5')	3.8M(12.4')

Installation

• Installation Overview




Figure 1

• Dual Gate Overview




Figure 2


Photocell Beam System, Warning Sign, Flash Lamp, Solar Panel, Gate Opener (Gate 2) (Left), Electric Lock, Gate Opener (Gate 1) (Right), Rubber Stopper

Important:


The gate opener cable should be put into the PVC conduit(not provided) which is buried underground. This protects the cable from lawn mowers and string trimmers.

• Installation Step

There are two installation types for the gate opener, check for Proper Gate Installation & Direction of Gate.



Pull-to-Open Option



Push-to-Open Option

NOTE: Ensure the gate does not open into public areas.

Step 1.

Ensure that the Post bracket height is in the same exact level with the gate bracket height. Failing to ensure accurate common heights will cause the motor arm to bend leading to failure. Also, the force to push or pull the gate will be reduced causing the motor to open or close the gates with difficulty or may not operate successfully at all. Severe different in height will damage the motor and the motor arm.




Figure 3

Step 2. Post Bracket Installation

Insert the Bolt ⑩ through the center hole of the post bracket and post pivot bracket as shown. Place the washer, nut on the bottom of the bolt and hand tighten.




Figure 4

Step 3. Install the Motor Fixed-End to the Gate Post-Bracket

- (1). Attached the gate bracket and post bracket assembly to the opener by inserting a clevis pin. Secure the clevis pins using the hairpin clips.




Figure 5

- (2). Open the release hole plug on the top of the gate opener, insert the release key, and turn the key 90° clockwise. This releases the motor and allows the push-pull rod to be manually extended and retracted. To restore normal operation, turn the key 90° counter clockwise.






Figure 6

Step 4. There are two installation types for the gate opener, check for Proper Gate Installation & Direction of Gate.

The adjustment operation of the limit switch is very important for helping you to install the gate opener.

Pull-To-Open Installation Mode:



The installation position of the bracket is very important. Please refer to the figure to measure according to the angle you need to open. Unit: mm (for example: A is 181mm, B is 132mm. At this time, the maximum opening angle of the gate is 100°), determine the center point of the shaft and mark it.



Pull to Open Assemble Instruction								
A	60	118	174	228	281	120	170	230
B	362	310	262	217	174	295	233	176
D	90°	90°	90°	90°	90°	100°	100°	100°

Push to Open Installation Mode

The installation position of the bracket is very important. Please refer to the figure to measure according to the angle you need to open. determine the center point of the shaft and mark it.



- (1). According to the diagram, the post bracket plate is attached the fixed bracket with an appropriate angle. Take out the gate opener arm to install the gate brackets and post brackets on the gate machine (the bracket angle is adjustable).

Adjusting different angles of Rear Bracket Fixed Plate to fit different Installing mode:





Figure 8

- (2). Fully open the gate (take 90° as an example) and retract the arm of the gate opener to the shortest position (when determining the position of the gate bracket on the gate, make the gate and the wall when the rear bracket is vertical). The post bracket is close to the wall, and the gate bracket is close to the gate body. Mark the position on the gate body with a marker.




Figure 9

- ②. Fully close the gate to 180°, extend the arm of the gate opener to the longest, place the gate bracket on the marked point on the previous gate, and observe whether the position is correct, drill holes at the marked position on the gate body to mount the bracket. Then the gate machine is placed horizontally, the position of the bracket is determined, and the hole is drilled. Hit the expansion screw to mount the brackets.




Figure 10

Note: It is recommended to open and close the gate back and forth by switching between the longest and shortest position of the gate opener's arm. Determine that the marked point is correct, and then insert perforated lock screws or weld to mount the brackets.

Step 5. Hole Installation/Welding

- (1). Fix the post bracket to the wall




Figure 11

- ① Construction drill and bolts:
 - a. Drill 4 holes of 8mm diameter.
 - b. Insert the 4 provided concrete Bolts⑧ and tighten properly (Do not over tighten as you may strip the bolt out of the concrete or the brick).
 - c. Place the motor connecting Bracket and tighten.
- ② Construction drill and Weld:
 - a. Drill 4 holes of 8mm diameter.
 - b. Locate the 4 slotted holes post bracket above the drilled Holes.
 - c. Weld the motor bracket to the post bracket.

(2) Motor drainage hole angle adjustment




Figure 12

Figure left, power cable and manual override release placed correctly

- 1** Post rear fixed bracket
- 2** Rear bracket fixed plate main motor arm
- 3** Lock pin

Figure right, power cable and manual Override release placed incorrectly

- 4** Rain drainage aperture
- 5** Washers and lock nuts
- 6** Power cable

Notice : Incorrect installation, Figure 12 right:

Cable must not be installed above the motor arm. It may pinch and strip the cable and causes electric shock. Also the manual override release must be located face to the view of the public. Follow correct installation as shown in Figure 8 left.

(3) Attach the rear bracket to the gate body




Figure 13

- a. Drill 2 holes of 10.2mm diameter with space 70mm between 2 holes
- b. Locate the 2 slotted holes gate bracket above the drilled holes
- c. **Place the end motor bracket to the gate bracket using the appropriate bolts and tighten properly (please note these bolts used to fixed front bracket to the gate are not provided due to the thickness of each gate is different)**
- d. Insert the lock pin and clamping washers

Step 6. Gate Rubber Stoper Installation




Figure 14

Step 7. Emergency Release Function





Figure 15

The schematic diagram of opening the gate body when there is no power is shown above. Please use the emergency release key to loosen the arm of the gate opener. Now you can manually open and close the gate.

How to adjust the limit switch for the swing gate opener


Overcurrent detection is a kind of way to control the mechanical movement from exceeding the limit position. For the swing gate opener, a limit stopper can stop the gate motor from exceeding an extended or retracted length. Adjustable the position of 2 limit stopper in the gate motor is designed to stop the actuator at a predetermined point during extension or retraction, which allows you to set the travel limits in accordance with your needs.

The swing gate opener is equipped with the limit stopper in the gate motor. When the motor is running and meet the limit stopper, then detect the overcurrent, the gate opener controller will cut off the power, and the motor will stop right now. The limit stopper is easy to adjust, and the gate will automatically stop on your desired position with this technology.



No matter dual or single swing gate openers, please note that

- Before adjusting the limit switch, make sure that the rod is fully retracted when the gate is in the fully opened position (for Pull-to-Open installation), or in the fully closed position (for Push-to-Open installation).
- The limit stopper are located on the arm underneath. For the purpose of adjustment only, you might find it easier to turn over the arm to access the limit switch screws. Once the adjustment is completed, please remember to turn back the arm to its correct position.
- Phillips Screwdriver is needed for adjustment.
- The position of Limit stopper A was fixed in factory, do not adjust it again as soon as possible.




Adjustments for Pull-to-Open Installation Mode

When the rod is entirely retracted, the gate is in the fully open position. Adjust the Limit Stopper B to determine the closed position:


When the rod is entirely retracted, the gate is in the fully open position. Adjust the Limit Switch B to determine the closed position:

1. Turn on power to operate the gate opener, then the rod will extend to close the gate.
2. When the gate is fully closed, press the remote control to make the gate opener to stop.
3. Measure the length of the rod moved. Such as it only moved 400mm to make the gate closed fully. But the whole length of the rod is 440mm, in order to make the gate opener stop in the desired closed position, you need to move the limit switch B inward with 40mm.
4. Use the screwdriver to loosen the screw of the Limit Switch B, slide it inwards.
5. Now the gate can arrive and automatically stop at the desired closed position. Then tighten the screw firmly.



Adjustments for Push-to-Open Installation Mode


When the rod is entirely retracted, the gate is in the fully closed position. Confirm the length of rod when it is fully opened, then slide the limit switch B inward with the rest length of the rod (such as $440 - 400 = 40$ mm). The process is totally same as the pull to open. Over the desired open position, slide the limit switch B inwards.



Control Board Instruction

Technical Parameters:

1. Control Panel Power: AC 19.6-21.6V DC24-28V
2. Back up battery: 12V lead-acid battery x 2
3. Application: Used for double or single DC 24V swing gate opener.
4. Encoder For transmitter: Factory owns rolling code.
5. Allowed Transmitters Quantity: Up to 128PCS.



1. Battery 1 and 2: connect with 2pcs 12V lead-acid battery.
 2. MOTOR 1: Slave gate, close first & open last. This terminal connects 1st red wire (counted from your left-hand side to your right-hand side)
 3. MOTOR 2 (Main) : Master gate, open first & close last. This terminal connects 1st blue wire (counted from your left-hand side to your right-hand side).
- NOTE! If you only have a single gate, the motor only can connect to the Motor 2 Main terminal.**
4. Ant: Connect with the antenna.
 5. COM: It is for connecting with the COM or GND.
 6. Card: It is for connecting to any external devices that will operate to open the gate.
 7. 2 SIDE: It is for connecting with any external devices that operates a double gate.
 8. 1 SIDE: It is for connecting with any external devices that operates the single gate.
 9. COM: It is for connecting to the COM or GND.
 10. Ph: Infrared terminal is for connecting with the photocell sensor.

- 11.VCC: The output is for connecting with the photocell sensor, etc devices, continuous output current $\leq 0.5A$.
- 12.Lock -: used for connecting with the “ground” of the lock.
- 13.Lock +: used for connecting with the electric lock
- 14.Lamp -: It is for connecting with the flash light -.
- 15.Lamp +: It is for connecting with the flash light +.
- 16.Power: It is for connecting with the AC transformer or DC 24V solar panel.
- 17.ON: power on/off button.
- 18.Menu: It is a digital display for showing you the setting data.
- 19.Touch: It is for connecting with the touch button, etc devices.
- 20.USB: It is for connecting with a USB device to upgrade the software.
- 21.DEC/Smart: used for figure decreasing of setting the data or operating the smart module.
- 22.FUN: Used for enter the menu setting and confirm the data.
- 23.INC/Start: used for figure increasing of setting the data or operating the single button control mode.
- 24.Learn: It is for programming/erasing the remote control.

• Remote Control

Each remote has 4 buttons, can set them with different work mode independently through the digital display menu L1, L2, L3 and L4,

- 0: No function.
- 1: Double gates open-Stop-Close...
- 2: Single gate open-Stop-Close...
- 3: Turn auto close off via remote
- 4: Open only.


Program new remote control:

- Press the Learn button on the control board for about 1 second, and the buzzer will sound with a short beep. The digital display will show the remote's number, which means the programming is successful.
- After you press the Learn button, if the board does not receive the new remote signal within 8s, the indicator LED will turn on and exit programming.
- Note: Due to the digital display only can show two digital numbers, if the controller already learned more than 99pcs remote, from the 100th remote, the digital display will show A to replace the ten and hundred digits. Such as the 100th remote will show A0, and the 101st remote will show A1. If the controller already learned more than 109pcs remote, from the 110th remote, the digital display will show b to replace the ten and hundred digits. Such as the 110th remote will show b0. And the 120th remote will show C0.
- Max capacity: 128pcs remote. If the digital LED shows “-” with a buzzer short beep 5 times, then means can not learn more remotes.


Erase remote control:

- Press and hold the Learn button for about 6 seconds. If the buzzer sound with a long beep, release the button and the digital display will show 00, which means remove all remotes successfully.

• Wire Diagram of the Control Board




Connect with control double gates device




Terminal ⑦2SIDE and ⑤COM are use to connect with push button for controlling dual gates.
If you connect with other control device, please connect with terminal ⑪ and ⑨ to get power supply.

Connect with swipe card




Terminal ⑪VCC and ⑨COM are used to supply power to swipe card device.
Terminal ⑥CARD and ⑤COM are use to connect with swipe card for controlling dual gates.

Connect with safety beam




Terminal ⑪ VCC and ⑨ COM are used to supply power to safety beam sensor.
So, connect terminal ⑪ VCC with the “+” of the safety beam sensor RX and TX .
Connect terminal ⑨ COM with the “-” of the safety beam sensor RX and TX.
Connect terminal ⑩ Ph with safety beam sensor “OUT”
Connect terminal ⑤ COM with safety beam sensor “COM”

Connection of Flash Lamp Device



Terminal ⑭ ⑮ Lamp + / - are used to connect with flash lamp.

Connect with electric lock



Terminal ⑫ LOCK- is used to connect with electric lock blue wire.
Terminal ⑬ LOCK+ is used to connect with electric lock red wire.

• Function Description of the Control Board

Function	State
Power On	The digital display will show EGA-18 00-U xx with a buzzer sound. If the indicator LED light on, means the system is working well.
Auto travel learning	<p>The newly installed motor needs to operate the auto travel learning once before the high and low speeds can be normally allocated.</p> <p>After the auto travel learning completed, the gate motor will automatically allocated the high and slow speed. The high and slow speeds for opening and closing can be set through the digital display menu.</p> <ol style="list-style-type: none"> 1. Before starting the auto travel learning, the gate must be fully closed. 2. Enter the menu, select Pr, set 5, and confirm to start the auto travel learning <p>Note: Auto travel learning will run at the slow speed set by the digital display menu; the port or remote control cannot be triggered during the learning process, otherwise the auto travel learning will be exited.</p> <p>If Pr set 10, you can also enter the auto travel learning, but this time it runs at the high speed set by the menu.</p> <p>It is recommended to select 5 to use the slow speed to learn the stroke. If after the slow speed auto travel learning, it is found that the high and low speed distribution of some gates is not ideal, you can try to use high-speed auto travel learning.</p>
Setting slow speed running time	<p>After completed the auto-travel learning, the gate opener will automatic set the slow speed running time for opening and closing from 0 - 5 levels. The bigger the value is, the more slow speed running time.</p> <p>0 means No slow speed running time.</p>
Setting running speed for opening and closing	<p>The gate opener can set the high speed and slow speed for opening and closing from 0 - 5 levels. The bigger the value is, the higher speed running.</p> <p>If adjust the running speed, please operate the auto-travel learning again.</p>
Motor overcurrent sensitivity setting	<p>The function can realize to anti crash the car and motor stop while the gate is opened or closed fully. While the gate is moving, it meets obstruction and will stop right now. The motor's overcurrent setting of high speed and low speed can be adjusted by the digital display menu.</p> <p>If the menu H3 set 1, while the gate is closing and detecting the obstruction, the gate will rebound to open fully.</p>
Setting gate mode	<p>The menu H4 can set the the gate mode is common gate or heavy duty gate, factory default is common gate mode.</p> <p>When the gate weight is heavy in the actual environment, the motor is easy to encounter obstructions and detect an overcurrent. So you need to set menu H4 is heavy duty gate mode.</p>
Limit mode	<p>The menu H3 can adjust the limit mode of the swing gate system.</p> <p>0 is overcurrent, while the motor runs with low speed and meet the obstacle, then detect the overcurrent, it is judged as a limit.</p> <p>1 is the limit switch. After the door machine runs in place, the limiter is disconnected. The system detects that the limiter is disconnected and determines that it is a limit.</p>

Safety beam mode	<p>The safety beam mode can be selected by menu, the default mode is 0, it is normal open mode.</p> <ol style="list-style-type: none"> 1.While the gate is closing, if the infrared signal meets an obstruction, the gate will rebound to open. 2.If set the auto-closing timer after fully opening, the gate will be auto-closed. 2. If the safety beam signal exists, the gate closing action will not be executed and the countdown time will always be reset.
Auto-closing timer for fully opening	<ol style="list-style-type: none"> 1.The auto-closing function is only triggered after the gate is fully opened. 2.Auto close timer for fully opening can be set through the digital display menu. 3.When auto-close timer start to countdown, the STATE LED will flash one time each second. 4.The remote button can set to cancel the auto-closing command once. 5.Note: Cancellation only cancels this time, and the gate can be auto-closing next time when it is fully opened.
Lamp mode	<p>The lamp work mode can be selected by menu.</p> <p>Mode 0: While the gate is moving, the lamp will light on. While the gate is stop moving, the lamp will turn off.</p> <p>Mode 1: While the gate is moving, and the lamp will light on. After 30s, the lamp will turn off.</p> <p>In addition, regardless of mode 0 or mode 1, the lamp will also light on during the countdown to closing the gate.</p>
Motor working time protection	<ol style="list-style-type: none"> 1.If the motor works continuously more than 60s, the motor will stop running for protection. 2. If the motor works continuously with low speed more than 30s, the motor will stop running for protection.
Setting of 1Side terminal	<p>The digital display menu can set the 1 SIDE terminal control mode.</p> <p>0: Double gates "Open-Stop-Close".....;</p> <p>1: Motor 2 "Open-Stop-Close".....(Factory defaults)</p> <p>2: Open only.</p> <p>3: Close only.</p> <p>4: Stop only.</p> <p>Note: mode 1 only apply in the motor 2. Other mode can be apply in double gates or single gate.</p>
Setting of 2Side terminal	<p>The digital display menu can set the 2 SIDE terminal control mode.</p> <p>0: Double gates "Open-Stop-Close".....(Factory defaults)</p> <p>1: Motor 2 "Open-Stop-Close".....</p> <p>2: Open only.</p> <p>3: Close only.</p> <p>4: Stop only.</p> <p>Note: mode 1 only apply in the motor 2. Other mode can be apply in double gates or single gate.</p>

Setting of swipe card terminal triggering	<p>The digital display menu can set the 2 SIDE terminal control mode.</p> <p>0: Double gates "Open-Stop-Close".....</p> <p>1: Motor 2 "Open-Stop-Close".....</p> <p>2: Open only.(Factory defaults)</p> <p>3: Close only.</p> <p>4: Stop only.</p> <p>Note: mode 1 only apply in the motor 2. Other mode can be apply in double gates or single gate.</p> <p>If trigger the swipe card terminal with mode 2 to open the gate fully, it will enter the auto closing timer after swiping card.</p>
Touch port	<p>It can connect the touch switch with the control box, has 2 channels.</p> <p>1.Control the motor 2 by Open-stop-close...</p> <p>2.Control the motor 1 and motor 2 by Open-stop-close...</p>
Lock mode	<p>1.The lock mode can be switched by menu.</p> <p>0:NC mode,power on when locked, used for electromagnetic lock.1:NO mode,power on when unlocked, used for electric lock.</p> <p>2. The control output time of the electric lock can be set by menu. If set to 0, it means turning off the function.</p>
Time delay with 2 gates for opening and closing	<p>Time delay with 2 gates for opening and closing can be adjusted separately by the menu. If user set 0, means No the delay function.</p> <p>If the delay function is active, when opening the door, motor 2 opens first then motor 1 opens later; while closing the door, motor 1 closes first then motor 2 closes.</p> <p>For the single gate system, this function does not work.</p>
Gate mode	<p>1.The gate mode can be switched by menu.</p> <p>0 is dual gates, which is a double gates opener system.</p> <p>1 is single gate, which is a single gate opener system.</p> <p>2.If the system is single gate system, all control for the double gates only operate on the main gate(Motor 2)</p> <p>3.If it is the single gate system, the motor must be connected with motor2 port.</p>
Smart charger function for back-up battery	<p>1. The system supports two 12V lead-acid batteries in series.</p> <p>2. The system has a built-in battery balancing function, which will automatically monitor the voltage of the two batteries during charging to prevent the two batteries from being damaged or insufficient due to imbalance.</p> <p>Note: The power port power supply needs to be properly connected, and the input voltage must match the battery to charge the battery normally.</p>

Upgrade control board system by USB device	<ol style="list-style-type: none"> 1. Before you upgrade the system, please confirm the U disk document is FAT32 or not. If not, please format the U disk as FAT32. 2. Copy the upgrade file into the root directory of the U disk and name it EGA-18.bin. 3. Insert the U disk into the upgrade module, and then connect the upgrade module to the USB port. 4. Enter the menu, select the Pr and set 5, and confirm. At this time, the system will restart, the digital tube will display UP, and the upgrade will begin. After the upgrade is completed, it will restart automatically.
Smart module port	<p>The XH-SG-WIFIBLE smart module can be connected externally to realize functions such as control, information reading, and settings. The smart module includes WiFi, Bluetooth and 2.4G functions.</p> <ol style="list-style-type: none"> 1. Add the Bluetooth control function on the phone APP: Press and hold the DEC/SMART button for 5s, the buzzer will sound twice. Release the button and the module will enter Bluetooth matching network mode. 2. Add the WiFi control function on the phone APP: Press and hold the DEC/SMART button for 10s, the buzzer will sound with a long beep. Release the button and the module will enter the AP matching network mode. 3. Program the 2.4G USB card transmitter: Press the DEC/SMART button once, the buzzer will sound a beep, and enter the programming mode. Power on the 2.4G USB card, and transmit a signal automatically. <p>If the smart LED flash three times, which means the programming operation is successfully. Otherwise, after 8s exit the programming mode.</p> <ol style="list-style-type: none"> 4. If you want to remove the 2.4G USB card, please press and hold the Learn button for 6s, until the buzzer sound with a long beep, then release the button. After that, all the remotes and USB cards can not control the gate. 5. When the programmed 2.4G USB card enters the receiving range of the module, it will trigger to open the gate once. <p>WiFi and Bluetooth functions support to connect with the phone app, which can realize functions such as controlling the gate with a mobile phone, adding and managing the remote controls, and menu settings the parameters. Please check the APP instruction manual for detailed functions.</p>
Factory Reset	<p>The factory reset needs to be performed at the factory to restore parameters to the default state; see the table below</p>

• Control Board Parameters Setting

- Press and hold the [FUN] button for 3 seconds, and the digital display will indicate “A0”, then release the button, now the menu can be set to [INC/START] and [DEC/SMART] for increasing and decreasing numbers or values.
- After adjusting the value, press the [FUN] button to store the data, and the buzzer will beep one time to show the store successfully.
- After the menu setting is finished, press the [LEARN] button to exit the menu setting and close the display.

<u>Item</u>	<u>Function description</u>	<u>Range</u>	<u>Default</u>	<u>Explanation</u>
<u>A0</u>	<u>Motor 2 opening overcurrent setting in high speed</u>	<u>0~20 level</u>	<u>10</u>	Motor 2 opening overcurrent setting in high speed, the bigger the value is, the harder the motor to stop. Setting value from 0-20
<u>A1</u>	<u>Motor 2 closing overcurrent setting in high speed</u>	<u>0~20 level</u>	<u>10</u>	Motor 2 closing overcurrent setting in high speed, the bigger the value is, the harder the motor to stop. Setting value from 0-20
<u>A2</u>	<u>Motor 2 opening overcurrent setting in slow speed</u>	<u>0~20 level</u>	<u>10</u>	Motor 2 opening overcurrent setting in slow speed, the bigger the value is, the harder the motor to stop. Setting value from 0-20
<u>A3</u>	<u>Motor 2 closing overcurrent setting in slow speed</u>	<u>0~20 level</u>	<u>10</u>	Motor 2 closing overcurrent setting in slow speed, the bigger the value is, the harder the motor to stop. Setting value from 0-20
<u>A4</u>	<u>Motor 1 opening overcurrent setting in high speed</u>	<u>0~20 level</u>	<u>10</u>	Motor 1 opening overcurrent setting in high speed, the bigger the value is, the harder the motor to stop. Setting value from 0-20
<u>A5</u>	<u>Motor 1 closing overcurrent setting in high speed</u>	<u>0~20 level</u>	<u>10</u>	Motor 1 closing overcurrent setting in high speed, the bigger the value is, the harder the motor to stop. Setting value from 0-20
<u>A6</u>	<u>Motor 1 opening overcurrent setting in slow speed</u>	<u>0~20 level</u>	<u>10</u>	Motor 1 opening overcurrent setting in slow speed, the bigger the value is, the harder the motor to stop. Setting value from 0-20

<u>A7</u>	<u>Motor 1 closing overcurrent setting in slow speed</u>	<u>0~20 level</u>	<u>10</u>	Motor 1 closing overcurrent setting in slow speed, the bigger the value is, the harder the motor to stop. Setting value from 0-20
<u>A8</u>	<u>Overcurrent sensitivity</u>	<u>0~3 level</u>	<u>0</u>	The bigger the value is, the longer the overcurrent sensing time is. Setting value from 0-3
<u>B0</u>	<u>Setting Motor 2 slow speed running time for opening</u>	<u>0~5 level</u>	<u>2</u>	Setting from 0-5, 0 means NO slow speed running time for opening
<u>B1</u>	<u>Setting Motor 2 slow speed running time for closing</u>	<u>0~5 level</u>	<u>2</u>	Setting from 0-5, 0 means NO slow speed running time for closing
<u>B2</u>	<u>Setting Motor 1 slow speed running time for opening</u>	<u>0~5 level</u>	<u>2</u>	Setting from 0-5, 0 means NO slow speed running time for opening
<u>B3</u>	<u>Setting Motor 1 slow speed running time for closing</u>	<u>0~5 level</u>	<u>2</u>	Setting from 0-5, 0 means NO slow speed running time for opening
<u>C0</u>	<u>Auto-closing timer for fully opening</u>	<u>0-99 seconds</u>	<u>0</u>	Setting from 0-99 seconds, 0 means No auto-closing for fully opening.
<u>C1</u>	<u>Auto-closing timer for swipe card terminal triggering</u>	<u>0-99 seconds</u>	<u>0</u>	0 means No auto-closing for swipe card terminal triggering.
<u>D0</u>	<u>Speed of Motor 2 high speed for opening</u>	<u>0~5 level</u>	<u>5</u>	Setting speed of high speed for opening, setting from 0-5
<u>D1</u>	<u>Speed of Motor 2 high speed for closing</u>	<u>0~5 level</u>	<u>5</u>	Setting speed of high speed for closing, setting from 0-5

<u>D2</u>	<u>Speed of Motor 2</u> <u>slow speed for</u> <u>opening</u>	<u>0~5 level</u>	<u>2</u>	Setting speed of slow speed for opening, setting from 0-5
<u>D3</u>	<u>Speed of Motor 2</u> <u>slow speed for closing</u>	<u>0~5 level</u>	<u>2</u>	Setting speed of slow speed for closing, setting from 0-5
<u>D4</u>	<u>Speed of Motor 1</u> <u>high speed for</u> <u>opening</u>	<u>0~5 level</u>	<u>5</u>	Setting speed of high speed for opening, setting from 0-5
<u>D5</u>	<u>Speed of Motor 1</u> <u>high speed for</u> <u>closing</u>	<u>0~5 level</u>	<u>5</u>	Setting speed of high speed for closing, setting from 0-5
<u>D6</u>	<u>Speed of Motor 1</u> <u>slow speed for</u> <u>opening</u>	<u>0~5 level</u>	<u>2</u>	Setting speed of slow speed for opening, setting from 0-5
<u>D7</u>	<u>Speed of Motor 1</u> <u>slow speed for</u> <u>closing</u>	<u>0~5 level</u>	<u>2</u>	Setting speed of slow speed for closing, setting from 0-5
<u>F2</u>	<u>Safety beam mode</u>	<u>0-1</u>	<u>1</u>	0: NC mode. 1: NO mode.
<u>F3</u>	<u>Flash Lamp Mode</u>	<u>0-1</u>	<u>0</u>	0: Flashing light and motor will operate and stop at the same time. 1: Flashing light will turn off 30 seconds after the motor stop.
<u>F6</u>	<u>Lock mode</u>	<u>0: NC</u> <u>1: NO</u>	<u>1</u>	NC mode: Normal close, power on when locked, used for electromagnetic lock. NO mode: Normal open, power on when unlocked, used for electric lock.
<u>F7</u>	<u>Electric lock working</u> <u>time setting</u>	<u>0~5</u> <u>seconds</u>	<u>2</u>	Used for setting the working time of electric lock. Setting from 0-5 seconds. 0 means electric lock disabled.

<u>G1</u>	<u>Setting of swipe card terminal</u>	<u>0~4</u>	<u>2</u>	0: Fully Open-Stop-Closefor double gates 1: Fully Open-Stop-Closefor single gate 2: Open only. 3: Close only. 4: Stop only.
<u>G3</u>	<u>Setting of 1 Side terminal</u>	<u>0~4</u>	<u>1</u>	0: Fully Open-Stop-Closefor double gates 1: Fully Open-Stop-Closefor single gate 2: Open only. 3: Close only. 4: Stop only.
<u>G4</u>	<u>Setting of 2 Side terminal</u>	<u>0~4</u>	<u>0</u>	0: Fully Open-Stop-Closefor double gates 1: Fully Open-Stop-Closefor single gate 2: Open only. 3: Close only. 4: Stop only.
<u>H0</u>	<u>Time delay with gate for opening</u>	<u>0-15 seconds</u>	<u>2</u>	0 means No time delay for opening 2 gates
<u>H1</u>	<u>Time delay with gate for closing</u>	<u>0-15 seconds</u>	<u>2</u>	0 means No time delay for closing 2 gates
<u>H2</u>	<u>Gate mode</u>	<u>0-1</u>	<u>0</u>	0: Double gates (Motor 1 and 2). 1: Single gate(Motor 2).
<u>H3</u>	<u>Limit mode</u>	<u>0-1</u>	<u>0</u>	0: Overcurrent. 1: Limit switch.
<u>H4</u>	<u>Setting gate mode</u>	<u>0-1</u>	<u>0</u>	0: Common gate mode. 1: Heavy duty gate mode.
<u>L1</u>	<u>Button A function (Remote control)</u>	<u>0-4</u>	<u>2</u>	0: No function. 1: Double gates open-stop-close... 2: Single gate open-stop-close... 3: Turn auto close off via remote 4: Open only.

<u>L2</u>	<u>Button B function</u> <u>(Remote control)</u>	<u>0~4</u>	<u>1</u>	0: No function. 1: Double gates open-stop-close... 2: Single gate open-stop-close... 3: Turn auto close off via remote 4: Open only.
<u>L3</u>	<u>Button C function</u> <u>(Remote control)</u>	<u>0~4</u>	<u>0</u>	0: No function. 1: Double gates open-stop-close... 2: Single gate open-stop-close... 3: Turn auto close off via remote 4: Open only.
<u>L4</u>	<u>Button D function</u> <u>(Remote control)</u>	<u>0~4</u>	<u>0</u>	0: No function. 1: Double gates open-stop-close... 2: Single gate open-stop-close... 3: Turn auto close off via remote 4: Open only.
<u>Pr</u>	<u>Trigger auto travelling learning</u>	<u>0-10</u>	<u>0</u>	Setting from 0-10. Set 5 will trigger the auto travel learning with slow speed. Set 10 will trigger the auto travel learning with high speed.
<u>PU</u>	<u>Upgrade the system by USB device</u>	<u>0-10</u>	<u>0</u>	Setting from 0-10. Set 5 will trigger to upgrade the system. 0 means No upgrade the system.
<u>Po</u>	<u>Factory reset</u>	<u>0-10</u>	<u>0</u>	Setting from 0-10. Set 5 will trigger to reset operation. 0 means No reset.

Control board digital display information show:

1. When the gate is opening, the digital display will show motor 1 is "OP", motor 2 is "OP.", and open double gates will show "O.P."
2. When the gate is closing, the digital display will show motor 1 is "CL", motor 2 is "CL.", and open double gates will show "C.L."
3. After the gate stop moving, the digital display will show the motor 1 is "--", motor 2 is "--.", and double gates will show "-.-."
4. When the motor is running at high speed and triggering the overload protection, the digital display will show motor 1 is "OH", and motor 2 is "OH.", and double gates will show "O.H."
5. When the motor is running at slow speed and triggering the overload protection, the digital display will show motor 1 is "OL", and motor 2 is "OL.", and double gates will show "O.L."
6. When the motor reaches max working time, the digital display will show motor 1 is "EC", and motor 2 is "EC.", and double gates will show "E.C."
7. When the safety beam is activated, the digital display will show "PH"
8. When the gate is opened fully, the motor 1 will show "LO", and the motor 2 will show "L.O"
9. When the gate is opened fully, the motor 1 will show "LC", and the motor 2 will show "L.C"
10. Cancel the auto-closing, the digital display will show "CC"

Motor direction identification:

When the motor is running, if the motor direction LED indicator is blue, now the motor should be in "opening" operation. When the motor direction LED indicator is RED, the motor should be in the "closing" operation.

Smart Module Instruction

Search "XHouse IOT" and download it from Google play or App Store



FOR Android & IOS

- Or scan this QR code for download APP "XHouse IOT" and install it.
- Register the account for "XHouse IOT" and log in.

Add the device

Step 1. Power on the device, open the APP. Press the "⊕" on the top right corner to add the device, then select the "Swinging Gate" which has a orange cycle on the top right corner. (Fig 1 and 2)

★ If there has a gray cycle on the top right corner, that means the device already be added. The user need to press and hold the "Dec/Smart" button for about 5s on the control board, then repeat the step 1.

★ If there has a message "Please enter distribution network mode and add devices", the user need to press and hold the "Dec/Smart" button for about 5s on the control board, then repeat the step 1.

Step 2. Select the Wi-Fi, click the "Connect" and enter the password.(Fig 3)

(If there hasn't Wi-Fi can be connected, the user also can select the "Bluetooth Add" and use the Bluetooth function to control the gate nearly. Please follow the step 4).

Step 3. Add the device successfully. The user can modify the name of the device and button from the "⚙️" on the top right corner. (Fig 5)

Step 4. Bluetooth Add: If the WiFi network is failure, you can choose the Bluetooth Add. When using Bluetooth mode control the device, the mobile app must be closed to the device within Bluetooth range for about 10m to connect and control it. (Fig 3 and Fig 4).




Fig 1




Fig 2




Fig 3




Fig 4




Fig 5

Device supports WiFi and Bluetooth working mode

- ★ When the device is connected to WiFi network successfully, it supports remote control and settings the device through the mobile phone APP. (Fig 5)
- ★ When the device is offline or the mobile phone has no network, if the user is nearly the device within 10 meters, and open the APP, it will automatically switch to the Bluetooth mode to control the device. (Fig 6)
- ★ The device will establish a Bluetooth connection with the mobile phone to achieve close-range Bluetooth control (only one user's mobile phone can establish a Bluetooth connection at the same time).




Fig 5




Fig 6

Switch a new WiFi network or switch the Bluetooth mode to WiFi mode

If the user need to switch to use a new WiFi network or want to switch control mode from the Bluetooth mode to WiFi mode, please follow the steps.

Step 1. Select the device, press the “⚙️” on the top right corner. Click the “Set/Modify WiFi”. (Fig 7)

Step 2. Select the new WiFi and connect it. And click the “Refresh”. (Fig 8)




Fig 7




Fig 8

Share the device

Step 1. Open the APP, select the device. Press the “⚙️” on the top right corner, then select to “Sharing device”, will create a QR code. (Fig 9)

Step 2. The new user download the APP and open it, Press the “Scan” on the top right corner to scan the QR code.(Fig 10)




Fig 9



Fig 10

Device settings

The user can set the parameters from the APP for the control board.

Step 1. Select the device, press the “⚙️” on the top right corner. Click the “ Setting”. (Fig 11)

Step 2. Set the parameters on the APP.(Fig 12)

Note: While the user want to set the parameters, the device must connect with the Wi-Fi. If not, the user need to use the Bluetooth function and put the phone app as close as the device to set the parameters. After done, please click the “Sync” button.




Fig 11




Fig 12

Apply to be engineer

When your customer's equipment fails, you can solve the problem by "Remote Assistance". So you need to apply to be engineer on the APP first. Click the "My" in the bottom of the APP, select "Apply to be engineer", enter the information to "Confirm application".




Fig 13

A screenshot of the "Confirm application" form. It contains the following fields: "Contact person:", "Contact information:", "Work experience:", "Can you repair motors:" (with "Yes" selected), and "Service point name:". At the bottom is an orange "Confirm application" button.

Fig 14

Remote assistance

When your equipment fails, the parameter settings need to be readjusted. At this time, you can directly initiate the "Remote Assistance" button and share the QR code or verification code with your installation service provider for the remote service.




Fig 15




Fig 16

Add USB card / RF remote control off site

When the user need to add a RF remote control or a USB card to open the gate, you can use the “Add USB card / RF remote off site” function to do it, and scan the QR code from the remote control or enter the ID number for the USB card. Don’t need to open the control box to program them.




Fig 17




Fig 18

Add USB card/RF remote at site

When the user needs to add an RF remote control or USB proximity card to open the door, you can use the "Add USB card/RF remote at site" function, click the "Learn" button, click "Start Learning". Don’t need to open the control box, and the control board will enter the code learning state, and then press the remote control button or power on the USB card to transmit a signal.




Fig 19




Fig 20

Management of the USB card and RF remote control

The card list can management your USB card and RF remote control. The user can sync all the cards and remotes to the card list for management, and delete it when they are no longer needed or lost. The card list can manage your USB card and RF remote control. The user can sync all the cards and remotes to the card list for management, and delete it when they are no longer needed or lost.




Fig 21

Binding with camera

Step 1. Open the APP, select the device. Press the “⚙️” on the top right corner, then select to “Binding camera”.

Step 2. Select the “IP camera”, and press the “confirm”.




Fig 22




Fig 23